
EMERGENCY MEDIAN OPENING EMO



ROAD SAFETY PRODUCT

MILLENIUM RELEASE SDN BHD



INTRODUCE

Millennium Release Sdn Bhd (MRSB)

Our company have 20 years of experience in Road Safety Furniture industry serve various clientele throughout Malaysia. We successfully undertaken more than 500 projects with contract value 50 -100 millions.






PRODUCTS

Emergency Median Opening

Emergency Median Opening are provided at locations on divided highways for crossing by maintenance, traffic service, emergency and low enforcement vehicles.





How it's works

Emergency Median Opening May Provide:

Where main line safety will not be compromised by providing a crossover Where access through interchanges is not practical

As part of region maintenance operations As necessary for low enforcement and emergency services functions

BENEFITS

1) Slide and swing EMO 2) Railing & NJB type 3) 40m long, 20m opening 4) Used M.S Rail 5) Jack system 6) Produced in Malaysia 7) Easley get spare parts / Low Maintenance 8) TL4 (Single Lock) TL5 (Double Lock)

Our Projects







EMO- installed on Jambatan Kedua Pulau Pinang in 2013



Continue



Continue

EMO- installed along North South Expressway and ELITE highway in 2015









Continue




EMO-SS installed East Klang Valley Expressway in 2021






EMO-NJB installed PENANG SECOND BRIDGE – Batu Kawan Penang



Oversea Project

EMO- installed in Brunei in 2017





Products specification

	Brand XX's Conventional EMO	MRSB's EMO
System Height	813mm	850mm
System Width	546mm	500mm
Weight Per Section	490kg	300kg
Minimum Installed Length	9m	8m
Maximum Installed Length	Unlimited (additional length increased by 4m)	Unlimited (additional length increased by 250mm)
No. of Jack	3 unit	1 unit
Connecting Pins	2 unit	2 unit(End Post)
Railing Type	Three beam	M.S Rail
Maintenance	Bulky and heavy structure, harder to clean debris and leaves under it.	Less heavy structure, easier to clean debris and leaves under it.
Price		Reasonable

SIRIM Certification

	TEST REPORT	SAMPLE REFERENCE : SAMPL STANDARD REFERENCE : MS EN1
REPORT NO : 202	23MT0788 PAGE : 1 OF 3	
International Sdn. Bhd. T forme (Including but not In & Environment (QOSHE).	only to samples submitted by the applicant to SIRIM GAS international Sdn. Bhd. and tested by SIRIM GAS his Test Report shall not be reproduced, except in full and shall not be used for any purpose by any means or mitted to advertising purposes) without withen approval from the Head of Gueilty, Occupational Safety and Health (SRM GAS International Sdn. Bhd. Please refer to the last page of this Test Report for Conditions Relating to	CLAUSE 7.3 MECHANICAL PROPERTIES (T
the Use of Test Report.		Yield Strength (MPa)
	HIS TEST REPORT IS ISSUED IN SECURED PDF SOFTCOPY	Tensle Strength (MPa)
Applicant	: MILLENNIUM RELEASE SDN. BHD. Lot 20031, Jalan CH Light Industries 2, 71700, Pajam, Negeri Semblian, Malaysia.	Elongation after fracture (%)
Manufacturer	: MILLENNIUM RELEASE SDN. BHD.	
Product	: Hot Rolled Plates and Strips of Non-Alloy Structural Steel	SAMPLE REFERENCE : SAMPL
Reference Standar Method of Test	Part 2 : Technical delivery conditions for Non-Alloy Structural Steels	STANDARD REFERENCE : MS EN
Description of some	Clause 7.3 - Mechanical properties – Tensile Test	
rescription of samp	ple : Two (2) samples of Hot Rolled Plates and Strips of Non-Alloy Structural Steel were received for testing.	7.3 MECHANICAL PROPERTIES (T
	Size : 1) 3.0 THK 2) 6.0 THK	Yield Strength (MPa) Tensile Strength (MPa)
Date Received of	: 12 June 2023	Elongation after fracture (%)
complete Applicati ob No.	: J20233080599	Note:
Description of Test Results		 Simple Acceptance Rule is used the Probability of False Accept is Where the reported uncertainty is level of confidence of approximation
ssued Date	: 23 June 2023	
Approved Signator	ny:	
		(The remainde
/	The And	
	unernatione the	
(NORAZ	CAN BIN ROSLAN	
Senior	Testing Executive	
	Testing Services Department	
		4
		1

PAGE: 2 OF 3

explicent to SIRIM QAS International Sdn. Bhd. and tested by SIRIM QAS used, except in full and shall not be used for any purpose by any means or forms written approval from the Head of Quality, Occupational Safety and Health & Please refer to the last page of this Test Report for Conditions Relating to the

1 - 3.0 THK, EMERGENCY MEDIAN OPENING (EMO) 025 - 2 : 2011

REQUIREMENT	RESULTS	REMARKS		
ILE TEST)				
275 min.	372	Pass		
410 to 560	493	Pass		
23.0 min.	33.0	Pass		

2 – 6.0 THK, EMERGENCY MEDIAN OPENING (EMO) 125 – 2 : 2011

REQUIREMENT	RESULTS	REMARKS	
ILE TEST)			
275 min.	335	Pass	
410 to 560	462	Pass	
23.0 min.	36.0	Pass	

the conformity statement. The level of risk regarding to 50%.

alculated using a coverage factor k=2, which gives a y 95%

this page is intentionally left blank)





Calculation Report

STRUCTURAL ANALYSIS CALCULATION REPORT

EMERGENCY MEDIAN

OPENIER

STRUCTURAL STABILITY CHECK

Akuan:

I here's out 's that there works have been designed by me in accordance with sound inginaring practice and that I take full n:ponsibility for the dusign and proper pe formance of the same.



	Impact Test Descri	•		
Test	Impact Speed	Impact Angle	Total Mass	Type of Vehicle
TB 32	110 km/h	20°	1.500 kg	Car

This report shows the EMO-SS The rail are expected to fail upon under assumption the crash cushion impact, therefore the rails are to be containment level is normal (N2), the replaced with a new one after crash. analysis used TB32 which is for 1.5ton The impact from the crash are car travelling at 110km/h at 20degree. transferred to the vertical post.

From the result it shows that In conclusion, the analysis shows the capacity of the vertical post and that the stability of the EMO-SS is steel base H-beam are able to sufficient. withstand the force from the impact from collision.

Product Warranty

We, **MILLENNIUM RELEASE SDN BHD**, hereby warrant that the products Manufactured are merchantable and free from defects in material and workmanship and in conformity with our standard specifications in effect at the time such products were manufactured for a period of TEN (10) year, from the date of delivery and installation. Our exclusive remedy for a defective product that fails under normal commercial use will be repair or replacement with a comparable product or component, free of charge.

Our warranty shall not apply in the event products are damaged as a result of misuse, abuse, neglect, accident, improper application, modification or repair or attachments to the product not approved by us and any damage caused from shipment by any persons not authorized by us.

The following materials and components below are covered by warranty from the date of installation:

Emergency Median Opening (EMOSS)

Works Title

Work Order No

Thank you

Deputy General Manager



MILLENNIUM RELEASE SDN BHD

WARRANTY CERTIFICATE

XXX XXX XX

XXX XXX XX XXX XXX XX

We, MILLENNIUM RELEASE SDN BHD, hereby warrant that the products Manufactured are merchantable and free from defects in material and workmanship and in conformity with our standard specifications in effect at the time such products were manufactured for a period of TEN (10) year, from the date of delivery and installation. Our exclusive remedy for a defective product that fails under normal commercial use will be repair or replacement with a comparable product or component, free of charge.

Our warranty shall not apply in the event products are damaged as a result of misuse, abuse, neglect, accident, improper application, modification or repair or attachments to the product not approved by us and any damage caused from shipment by any persons not authorized by us.

The following materials and components below are covered by warranty from the date of installation:

Emergency Median Opening (EMOSS)

No products will be accepted for return without prior approval. We shall have the right to inspect any products claimed as a defective product at the installation place, or require the buyer to return the product to us for inspection at our premises.

Transportation charges covering returned products will be borne by us only if such products are proven to be defective, are covered by this warranty, and are returned within the warranty period stated above.

For MILLENNIUM RELEASE SDN BHD

NOOR HIDAYAH BINTI ABDULLAH

THANK YOU

CONTACTS MILLENNIUM RELEASE PAJAM , NILAI NEGERI SEMBILAN MALAYSIA HP +6017 311 4178 (Pn.Nor) +6019 387 0026

